


How to set up a CTP system and use the CleverSparky app –

without using the LED scanning feature

Step 1 – Before installing the fittings

Ensure all fittings have an ID number and QR code attached before installing.




*Labels included in carton

Step 2 – Charge batteries

Charge the batteries for 16 hours.

Step 3 – Activate the CTP function and perform the initial 120 minute self-test


Use the circuit breaker to activate the CTP self-test function by switching the lighting circuit on and off in the following sequence: (use a stopwatch as the timer needs to be accurate).




The 120min self-test will now begin.

Step 4 – Enter site details

Download and open the CleverSparky App and **Add your Site** details and a group name that identifies the area of the fitting.




Select your group and press “Manually add fitting.” Enter in the fitting ID and location details.




Step 5 – Create the electronic logbook

Click on the **Create New logbook** button.



Enter test **collection date**, **date the fitting tested** and **duration required** to pass this test. (120min for initial test and 90min for subsequent tests).



Add your testing groups to the collection and select one to begin collecting results.



Step 6 – Collect the test results

- Press the **Quick Collect** button, select one fitting at a time or **Select All**.
- Walk to each fitting and inspect the flashing LED. The LED will flash fast Green for 20 sec (Scanning mode) then a 10 sec visual mode. During the visual mode look for the very slow amber and green flash or a solid green which indicates a pass.

VERY SLOW AMBER & GREEN FLASH*

(4s amber, 1s Green)

If battery is disconnected, 3s off

RECENTLY PASSED. The fitting has passed a test. This indication remains for 5 days after the test and then changes to green.



- Create your logbook entry.
- Select your group for collection.
- Walk through and view the Status LED of the CTP fittings.
- Tap each fitting to select it.
- Press Pass or Fail .
- Save your collection.
- Send a test report to your email.